

# ASSEMBLY INSTRUCTIONS

## INTERNAL POCKET RAIL ASSEMBLY

**1.** REMOVE THE NUTS AND BOLTS THAT HAVE BEEN TEMPORARILY ATTACHED TO THE METAL BRACKETS INSTALLED ON THE CORNER POCKET ASSEMBLY.



**2.** ALIGN THE DOWELS IN THE CORNER POCKET ASSEMBLY WITH THE DOWEL HOLES ON THE SIDE RAIL. PRESS TOGETHER BY HAND. THE WOOD TABS WILL HELP TO ALIGN THE BLINDS.

ALIGNMENT  
TABS.

ALIGNMENT  
DOWELS.



**3.** USE THE ALLEN WRENCH PROVIDED TO TIGHTEN THE RAILLOCK FASTENER. SIMPLY INSERT THE ALLEN KEY INTO THE ACCESS HOLE ON THE CORNER ASSEMBLY AND TURN CLOCKWISE 90 DEGREES. DO NOT OVERTIGHTEN.

ACCESS  
HOLE FOR  
RAILLOCK  
FASTENER.



**4.** USE THE NUTS AND BOLTS REMOVED DURING STEP 1 TO FASTEN THE METAL BRACKETS TOGETHER. THIS WILL CLOSE THE GAP BETWEEN THE CORNER ASSEMBLY AND SIDE / END RAILS AND PROVIDE A STRONG CONNECTION.



**5.** REPEAT STEPS 1-4 TO COMPLETE THE ASSEMBLY OF THE INTERNAL POCKET RAIL SET.

