



California House uses a 3-degree angle swivel in most swivel barstools. This 3-degree angle contributes to the overall comfort of your stool.


If you find the stool(s) leaning forward, tilted to the side, or varying heights, your stool is not assembled correctly.

Please make sure the wide side of the swivel is pointed to the front of the seat, and the narrower side of the swivel is facing the rear.

**NARROW SIDE
TO BACK
OF SEAT**



**WIDE SIDE TO
FRONT
OF SEAT**



**WIDE SIDE TO
FRONT
OF SEAT**

**Note: The swivel is
stamped "FRONT"
pointing to the front
of the seat.**