


ASSEMBLY INSTRUCTIONS


DISTRICT BASE AND CHASSIS




- 1** OPEN THE CARTON CONTAINING THE CHASSIS. PLACE THE CHASSIS UPSIDE-DOWN ON A PROTECTED SURFACE SUCH AS THE PACKAGING THAT IT CAME IN (SO THAT YOUR FLOOR IS NOT DAMAGED.)



- 2** OPEN THE CARTON CONTAINING THE LEGS. SET THE LEGS IN PLACE AS SHOWN. USE THE 2 1/4" BOLTS AND WASHERS PROVIDED TO FASTEN EACH LEG IN PLACE. FIRST INSTALL THE BOLTS BY HAND, CHECK THAT THE LEGS ARE FLUSH WITH THE ENDS OF THE CHASSIS, AND THEN TIGHTEN FIRMLY WITH A SOCKET WRENCH.




2 1/4" BOLT WITH WASHER




- 3** FLIP THE ASSEMBLED TABLE UPRIGHT AND POSITION THE SLATE IN PLACE. THE SLATE SHOULD BE CENTERED INSIDE THE CHASSIS SO IT'S BORDER IS ABOUT 1 1/4" FROM THE INSIDE EDGE OF THE CHASSIS ON THE SIDES AND ENDS. AT THIS POINT IT IS A GOOD IDEA TO SET THE RAIL FRAME IN PLACE TO MAKE SURE THE SLATE HOLES LINE UP WITH THE THREADED HOLES IN THE BOTTOM OF THE RAIL FRAME. WHEN IT IS PROPERLY POSITIONED, SECURE THE SLATE USING THE 2 1/2" PHILLIPS SCREWS PROVIDED. PREPARE SLATE AS NECESSARY WITH JOINT FILLER AND FABRIC COVER.



2 1/2" PHILLIPS SCREW



- 4** AFTER APPLYING COVER TO THE RAIL FRAME, LIFT IT IN PLACE ON THE TABLE. CENTER THE RAIL FRAME ON THE CHASSIS AND LEGS. USE THE SCREWS PROVIDED TO FASTEN THE RAIL FRAME TO THE CHASSIS. WHEN IT IS FASTENED FIRMLY IN PLACE, USE THE 1 3/4" BOLTS WITH COMPRESSION WASHERS TO FURTHER FASTEN THE RAIL FRAME TO THE SLATE.



1 3/4" BOLTS WITH COMPRESSION WASHER

